



TJ Steering Box Skid Plate (SBSPT)



Fits TJ wranglers '97-current

1. Remove the driver side lower bumper bolt.
2. Hold skid plate in place, placing the largest of the three holes in the skid plate over the hole from the bumper bolt.
3. With the skid plate in place, replace the bumper bolt.
4. Use flat washers to correct the spacing of skid plate when using stock bumper.
5. Use the existing hole in the frame to line up the rear skid plate bolt. Put the nut inside the frame.
6. Put the spacer in place and install bolt.
7. With the skid plate in place, locate the remaining hole in the rear of the skid plate. Using the hole as a guide, use a center punch to mark the location you will be drilling.
8. Use a 5/16" drill bit to drill the frame at the location you just marked.
9. Screw the self-tapping bolt into the hole you just made and tighten.

Tera Manufacturing, Inc.

5251 South Commerce Dr. Murray, Utah 84107

Phone/801.288.2585 Fax/801.288.2571

www.teraflex.biz